



Fountain Light Kit Installation Instructions For Kasco 2 hp & Larger Fountains

Thank you for purchasing the SLK3N fountain light kit. The SLK3N kit will transform your fountain into a beautiful night time display. These rugged stainless steel lights will provide years of reliable service.

Your light kit requires a small amount of assembly:

1. Attach the aluminum bracket to the float by removing the outer bolt on each float section. Insert the aluminum bracket over the fountain bracket and re-install bolt (see picture).
2. The junction box (located approximately 3' back from lights) attaches to the fountain power cord using two of the black cable ties included with your kit. Any extra cord between the junction box and the light **MUST BE SECURED** to the fountain. Failure to do this could result in the cord becoming sucked into the fountain impeller and will void the warranty!
3. Mount the transformer/timer in a secure location. The transformer is weatherproof and does not need to be protected from the weather. The photo eye on the transformer will turn on the lights at dusk. Turn the knob on the transformer to select four, six or eight hours of operation after dark.
4. Over time the lights will appear dimmer than when new. This is caused by algae or sediment on the lens of the light. This can be easily removed with a small brush (a toothbrush works great!).





Fountain Light Kit Installation Instructions

For Kasco 1/2 hp, 3/4 hp & 1 hp Fountains

Thank you for purchasing the SLK3N fountain light kit. The SLK3N kit will transform your fountain into a beautiful night time display. These rugged stainless steel lights will provide years of reliable service.

Your light kit requires a small amount of assembly:

1. Attach the aluminum bracket to the float with the bolts provided (see picture).
2. The junction box (located approximately 3' back from lights) attaches to the fountain power cord using two of the black cable ties included with your kit. Any extra cord between the junction box and the light **MUST BE SECURED** to the fountain. Failure to do this could result in the cord becoming sucked into the fountain impeller and will void the warranty!
3. Mount the transformer/timer in a secure location. The transformer is weatherproof and does not need to be protected from the weather. The photo eye on the transformer will turn on the lights at dusk. Turn the knob on the transformer to select four, six or eight hours of operation after dark.
4. Over time the lights will appear dimmer than when new. This is caused by algae or sediment on the lens of the light. This can be easily removed with a small brush (a toothbrush works great!).

