# AF50 • AF100 • AF1002





AF50 (1/2 hp, 115 volt) AF100 (1 hp, 115 volt) Both include timer & GFCI panel

**AF1002** (1 hp, 230 volt) Includes timer but NO GFCI - For proper unit operation, you must purchase GFCI locally.

# **PRODUCT SPECS**

## **AF50**

1/2 hp • 115 volt • 7.0 amps 60 GPM (approx.) Wide Umbrella Spray: 6' H x 15' Dia. Rocket Spray: 8' H x 2' Dia.

### **AF100**

1 hp • 115 volt • 11.0 amps 90 GPM (approx.) Wide Umbrella Spray: 8' H x 26' Dia. Rocket Spray: 16' H x 5' Dia.

#### AF1002

1 hp • 230 volt • 5.5 amps 90 GPM (approx.) Wide Umbrella Spray: 8' H x 26' Dia. Rocket Spray: 16' H x 5' Dia.

# AquaF@untain...

# INSTALLATION INSTRUCTIONS

Thank you for your purchase of an EasyPro® AquaFountain™. Your AquaFountain™ will enhance the beauty of your pond or lake for many years with reliable performance. Each EasyPro® AquaFountain™ comes pre-assembled for easy installation.



## SAFETY & HANDLING INSTRUCTIONS

- Under NO circumstances should anyone enter the water with the electrical plugged in and/or in operation.
- Exercise caution with any electrical equipment with moving parts.
- Never run the unit out of the water. This can cause damage to the unit and is dangerous for the operator.
- Units not for use in brackish or saltwater applications
- Never lift or pull the unit by the power cord.
- Do not use waders in deep ponds/lakes or in ponds/lakes with drop-offs, drastic slopes or soft bottom material.
- Do not use boats that tip easily for fountain installation. Follow ALL boating safety rules and regulations, including wearing a PFD (Personal Flotation Device).
- To reduce the risk of electric shock, the units should be plugged into a GFCI breaker that is properly grounded. Be sure to test the GFCI breaker upon installation and every month thereafter to ensure proper operation.

## INSTALLATION

- Remove unit and power cord from packaging. Inspect unit for any damages from shipping. Notify the shipping company immediately, or your EasyPro® dealer about any damages.

  (Optional Step: A light kit may be installed on the fountain before launching unit in the water. Follow the installation instructions included with the EasyPro® Light Kit.)
- 2. Choose either the Wide Umbrella or Rocket nozzle to install. To interchange the nozzles, simply remove the black cover, and thread the nozzle into the fountain head. Nozzle slots may vary slightly. (Narrow Umbrella nozzle option sold separately.)







Wide Umbrella

Rocket

Narrow Umbrella