



Box Style Fill Valve

Instructions for Installation into EasyPro Pond Skimmers

The BFS fill switch is a compact, easy to install fill valve that can be used in a variety of applications. Unlike most fill valves which have an arm sticking out that can be easily bumped or broken, this valve has an internal float inside of a plastic body which protects it from damage.

As the red float raises up inside the black float housing the flow will diminish. When the water reaches the fill line the flow will cease.


To install this valve in a skimmer you will need to drill two $\frac{5}{16}$ " holes in the side of the skimmer above water line.

Remove one of the nuts from each of the two bolts. Do not remove the second nut from each of the bolts, these act as a spacer between the hanger brackets and the inside of the skimmer.

Install the fill valve from the inside of the skimmer with the bolts sticking through the wall of the skimmer. Secure with the two nuts removed earlier.

You will need to drill a hole in the wall of the skimmer for the incoming water line. The fitting on the fill valve is barbed and sized for $\frac{1}{2}$ " tubing.

Slide the tubing over the fitting and clamp. We recommend an in-line pressure regulator in your incoming line to reduce the line pressure if your fill valve does not shut off completely. Maximum water pressure is 55 PSI, however, at pressure over 40 PSI water may drip from valve when the float is up. An inline pressure regulator can be installed before the supply line connects to the auto fill — this will allow you to control the water pressure if it is too high.



EASYPRO POND PRODUCTS LIMITED WARRANTY

EasyPro Pond Products Limited Warranty

EasyPro Pond Products ("EasyPro") warrants to the purchaser that this product ("Product") will be free from any mechanical or material defects for a period of **one year** from the date of purchase. This warranty only covers properly installed and maintained Products sold by authorized EasyPro Sellers who are subject to and follow EasyPro's quality control standards. Please note that because EasyPro is unable to control the quality of Products sold by unauthorized sellers, unless otherwise prohibited by law, this warranty does not cover Products purchased from unauthorized sellers.

This warranty does not cover normal wear and tear, nor any deterioration suffered through overloading, improper use, negligence, improper installation, acts of God or accident. Similarly, any modification made by the purchaser to the Product will cause the warranty to be null and void. This warranty does not cover any cost associated with the installation or removal of the Product subject to a warranty claim.

All returned items will be inspected to determine cause of failure before a warranty claim is approved. The exclusive remedies provided hereunder shall, upon EasyPro's inspection and option, be either repair or replacement of the Product or parts covered under this warranty.

Making a Claim: A Return Authorization ("RA") number must first be obtained by calling EasyPro at 800-448-3873 or via email at warranty@easypro.com. It is the purchaser's responsibility to pay the return shipping charges. Be sure to include the RA number, original receipt (in the form of an invoice or sales receipt), your name, your return address and your phone number inside of the package. No warranty claims will be honored without the original receipt that shows that your purchase was made from an Authorized EasyPro Seller. Ensure the product is properly packaged and insured for the replacement value. Damage due to improper packaging is the responsibility of the sender.

ALL OTHER EXPRESS OR IMPLIED WARRANTIES INCLUDING MERCHANTABILITY OF FITNESS FOR A PARTICULAR PURPOSE ARE HEAREBY LIMITED IN DURATION TO THE DURATION OF THE WARRANTY AS DESCRIBED ABOVE. Some States do not allow limitations on how long an implied warranty lasts, so the above limitations may not apply to you.

EasyPro shall not be held liable for any damages caused by defective components or materials of this Product; or for loss incurred because of the interruption of service; or any consequential/incidental damages and expenses arising from the production, sale, use or misuse of this Product. Some States do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you.

EasyPro shall not be held liable for any loss of fish, plants or any other livestock as a result of any failure or defect of this Product. This warranty gives you specific legal rights, and you may also have other rights that vary from State to State.