KLC25FK Filter Kit



Filter Kit Instructions for KLC25 Compressor

Includes:

- 1 Small round filter
- 1 Retainer ring (color may vary)
- 1 Air inlet filter



Remove old filter elements from compressor. These can be saved and cleaned if in adequate condition. Pinch clamps and connecting tube will be re-used.

Install round filter into the inlet side. See bottom of unit for identification.



Install retainer ring to hold filter into place.



Install the air inlet filter as shown. Be sure to install on the inlet side only.

