



Water Fill Box Instructions



The water fill box is a convenient location to mount your autofill valve. Installing an autofill inside a skimmer or in a pondless waterfall vault can be difficult depending on the size of pump being used and the size of the autofill valve. The water fill box lets you mount your autofill anywhere around the perimeter of the pond or pondless reservoir.

The water fill box comes with a pre-installed $\frac{1}{2}$ " bulkhead fitting in the end that the autofill mounts to. Use Teflon tape on all threads.

Use the grey male adapter on the outside of the fill box. Wrap the threads in Teflon tape and tighten into the bulkhead fitting on the outside. Connect the $\frac{1}{2}$ " irrigation line to the fitting and clamp.



By creating a small flat shelf at the most convenient place around the perimeter of your pond, you can easily conceal the fill box (see illustration at right).



When using in a pondless setup, install the water fill box at approximately the same height as the top of the pump. This way if the water level drops, the autofill will add water and protect the pump.

The top of the three cutouts on the front of the water fill box is the recommended water level. The autofill itself can be adjusted to fine tune the water level.

The 1" bulkhead in the back wall of the water fill box is an optional overflow. If a highwater overflow is needed in your feature you can connect a drain line to this bulkhead to drain off excess water. If another drain is already present (i.e. in skimmer, etc.) then this bulkhead can be ignored.



EasyPro Pond Products Limited Warranty

EasyPro Pond Products ("EasyPro") warrants to the purchaser that this product ("Product") will be free from any mechanical or material defects for a period of **five years** from the date of purchase. This warranty only covers properly installed and maintained Products sold by authorized EasyPro Sellers who are subject to and follow EasyPro's quality control standards. Please note that because EasyPro is unable to control the quality of Products sold by unauthorized sellers, unless otherwise prohibited by law, this warranty does not cover Products purchased from unauthorized sellers.

This warranty does not cover normal wear and tear, nor any deterioration suffered through overloading, improper use, negligence, improper installation, acts of God or accident. Similarly, any modification made by the purchaser to the Product will cause the warranty to be null and void. This warranty does not cover any cost associated with the installation or removal of the Product subject to a warranty claim.

All returned items will be inspected to determine cause of failure before a warranty claim is approved.

The exclusive remedies provided hereunder shall, upon EasyPro's inspection and option, be either repair or replacement of the Product or parts covered under this warranty.

Making a Claim: A Return Authorization ("RA") number must first be obtained by calling EasyPro at 800-448-3873 or via email at warranty@easypro.com. It is the purchaser's responsibility to pay the return shipping charges. Be sure to include the RA number, original receipt (in the form of an invoice or sales receipt), your name, your return address and your phone number inside of the package. No warranty claims will be honored without the original receipt that shows that your purchase was made from an Authorized EasyPro Seller. Ensure the product is properly packaged and insured for the replacement value. Damage due to improper packaging is the responsibility of the sender.

ALL OTHER EXPRESS OR IMPLIED WARRANTIES INCLUDING MERCHANTABILITY OF FITNESS FOR A PARTICULAR PURPOSE ARE HEREBY LIMITED IN DURATION TO THE DURATION OF THE WARRANTY AS DESCRIBED ABOVE. Some States do not allow limitations on how long an implied warranty lasts, so the above limitations may not apply to you.

EasyPro shall not be held liable for any damages caused by defective components or materials of this Product; or for loss incurred because of the interruption of service; or any consequential/incidental damages and expenses arising from the production, sale, use or misuse of this Product. Some States do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you.

EasyPro shall not be held liable for any loss of fish, plants or any other livestock as a result of any failure or defect of this Product. This warranty gives you specific legal rights, and you may also have other rights that vary from State to State.



800-448-3873 • Grant, Michigan
www.easypro.com