

LED2W • LED2K



Submersible, Bright Mini LED Lights

Instructions for Operation • Safety • Warranty



LED2W

LED2K

Thank you for purchasing the EasyPro Mini LED pond lights. With these lights you can make your fountain glow, illuminate your pond from within, highlight your waterfall from inside and outside the pond and extend the enjoyment of your water feature in the evening hours. This light may be used outside of the pond as landscape lighting as well. With these low voltage lights you can connect 8 lights to one 10 watt transformer (1.25 watts per fixture). LED2K includes: three lights with 10 watt transformer.

Safety and Electrical Connections

1. Always disconnect the electrical supply before handling, maintaining, repairing or installing any pond equipment.
2. Light(s) must be attached to a UL listed transformer.
3. Never hook the lights directly to a 110 volt or higher outlet.
4. Connect the transformer to a 110 volt receptacle that is protected by a Ground Fault Circuit Interrupter (GFCI).
5. Do not use this product in bathrooms or swimming pools.
6. All electrical work must be performed by a qualified technician. Always follow the National Electrical Code (NEC) or the Canadian Electrical Code as well as all local, state and provincial codes. Code questions should be directed to your local electrical inspector. Failure to follow electrical codes and OSHA safety standards may result in personal injury or equipment damage. Failure to follow manufacturer's installation instructions may result in electrical shock, fire hazard, personal injury or death, damaged equipment, provide unsatisfactory performance and may void manufacturer's warranty.

Installation

1. Before installing the product make sure to check in the box for damaged or missing parts. Contact EasyPro immediately if pieces are missing or damaged.
2. Be sure the power is disconnected before installing the lights.
3. Place the light in the desired location of your water feature.
4. Run the cable back to the transformer.

5. When installing the light cable, run the wire back to the transformer and remove the protective cap off of one of the terminals on the transformer. Insert the two prong plug into the terminal and screw down the nut to make a weather tight seal.
6. Install transformer on a timer and enjoy.
7. Recommended 12 volt transformer for use with multiple lights is the MT10/10 watt. (Included with the LED2K kit.)



Service and Maintenance of Submersible Lights

1. Disconnect the transformer from the power supply before service.
2. All parts of the lighting system should be checked on a regular basis to make sure the system is functioning properly.
3. The LED bulbs are not replaceable.
4. If the light output seems to be diminished, clean the lens with a clean damp cloth.

Replacement Parts and Accessories for Mini LED Lights - LED2

- 15' extension with six outletsLEDEX6
10 watt transformerMT10

EasyPro Pond Products Limited Warranty

EasyPro Pond Products ("EasyPro") warrants to the purchaser that this product ("Product") will be free from any mechanical or material defects for a period of two years from the date of purchase. LED2W fixtures must be installed on a magnetic 12v AC low voltage system. Removal of Quick Connect ends will void warranty. This warranty only covers properly installed and maintained Products sold by authorized EasyPro Sellers who are subject to and follow EasyPro's quality control standards. Please note that because EasyPro is unable to control the quality of Products sold by unauthorized sellers, unless otherwise prohibited by law, this warranty does not cover Products purchased from unauthorized sellers. This warranty does not cover normal wear and tear, nor any deterioration suffered through overloading, improper use, negligence, improper installation, acts of God or accident. Similarly, any modification made by the purchaser to the Product will cause the warranty to be null and void. This warranty does not cover any cost associated with the installation or removal of the Product subject to a warranty claim. All returned items will be inspected to determine cause of failure before a warranty claim is approved. The exclusive remedies provided hereunder shall, upon EasyPro's inspection and option, be either repair or replacement of the Product or parts covered under this warranty.

Making a Claim: A Return Authorization ("RA") number must first be obtained by calling EasyPro at 800-448-3873 or via email at warranty@easypro.com. It is the purchaser's responsibility to pay the return shipping charges. Be sure to include the RA number, original receipt (in the form of an invoice or sales receipt), your name, your return address and your phone number inside of the package. No warranty claims will be honored without the original receipt that shows that your purchase was made from an Authorized EasyPro Seller. Ensure the product is properly packaged and insured for the replacement value. Damage due to improper packaging is the responsibility of the sender. ALL OTHER EXPRESS OR IMPLIED WARRANTIES INCLUDING MERCHANTABILITY OF FITNESS FOR A PARTICULAR PURPOSE ARE HEREBY LIMITED IN DURATION TO THE DURATION OF THE WARRANTY AS DESCRIBED ABOVE. Some States do not allow limitations on how long an implied warranty lasts, so the above limitations may not apply to you. EasyPro shall not be held liable for any damages caused by defective components or materials of this Product; or for loss incurred because of the interruption of service; or any consequential/incidental damages and expenses arising from the production, sale, use or misuse of this Product. Some States do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you. EasyPro shall not be held liable for any loss of fish, plants or any other livestock as a result of any failure or defect of this Product. This warranty gives you specific legal rights, and you may also have other rights that vary from State to State.



800-448-3873 • Grant, Michigan
www.easypro.com